


designation of cylinders



firing order : 12-1-8-5-10-3-7-6-11-2-9-4

